


Log into your AWN account



Go to Devices and then click on the Ambient symbol

RainWise Sensor Settings

Sensors

SOLAR RADIATION SOLAR RADIATION 2 LEAF WETNESS TEMPERATURE 1 TEMPERATURE 2 SOIL MOISTURE 1

Note: Check these boxes only if you have the affiliated add on sensors

Offsets

BAROMETER +/- x.xx in.

INSIDE TEMP +/- x.x

AIR TEMP +/- x.x

[Delete this device](#)

Scroll down the screen and you can enter any offsets here.